

# Slide adaptor kit for Imacon Flextight Precision scanner

## Installation:

1. Check that the installed colorflex version is 1.9.6 or later. If the version is older please update, using the enclosed CD rom.

2. Mount the slide table by pushing the table into the scanner. A click should be heard to indicate that the table is locked.

*See illustration*



3. To remove the table, the rear end of the table is lifted to release the springs.

*See illustration*



## To scan a slide:

1. Place the slide mount in the slide holder by pushing it into the holder. Once the slide is in the holder, make sure that the slide is lying flat.

*See illustration*



2. When the slide mount is in the holder scanning can be performed as usual. Select "35 mm Slide" in the Colorflex frame menu.

*See illustration*

